

## Replacing and Purchasing Consumable Parts

The gasket and cap are consumable parts. Check once a year for damage/deterioration. If heavily stained or loose, replace them.

For replacements, contact the shop where you purchased this product.

## Inquiries

The utmost measures have been taken to ensure the quality of this product. Should the product be defective, however, contact your dealer and provide the following information.

1. Product name
2. Model Number
3. Description of trouble  
(As detailed as possible)

Feel free to send any questions or comments about this product to the shop where you purchased it.



MODEL  
**MMP-A**

# Stainless Steel Mug

## Instructions

Thank you for purchasing a "TIGER" Stainless Steel Mug.  
Please read the instructions completely before use.  
Keep these instructions for future reference.



# SAHARA MUG




**TIGER CORPORATION**  
Head Office: 3-1 Hayamicho, Kadoma-City, Osaka, 571-8571 Japan

## Safety Precautions

Keep out of reach of children.

Close the cap tightly when the bottle is full.

Do not fill the bottle above the fill-up limit point shown below.



Do not put dry ice or carbonated beverages in the bottle.

Do not place the bottle near stoves, open flames, or other sources of extreme heat.

Do not use the bottle for any purposes other than keeping beverages warm or cold.

Do not heat the bottle in a microwave oven.

Do not disassemble or attempt to repair the bottle by yourself.

## For Best Results

The following may cause the quality of the product to deteriorate.

- Storing milk, dairy products, or certain fruit juices in the bottle.
- Storing soups or beverages containing salt in the bottle.
- Using chlorine-based bleaches when cleaning the bottle.

The following may cause spills, diminish the bottle's ability to maintain beverage temperatures, or otherwise damage the product.

- Knocking over, dropping, or exposing the bottle to excessive shocks.
- Removing the protective sheet on the underside of the bottle.
- Placing the bottle on its side.

1

## How to Clean

- ◆ Clean after every use.
- ◆ Use synthetic kitchen detergent (for plates and cooking utensils).
- ◆ Use a sponge or soft piece of cloth.
- ◆ Clean the cap and gasket thoroughly to prevent odors.


### Caution

- Wipe the bottle with a dry cloth immediately after washing.
- Do not use dishwashers / dishdryers or boiling water.

### Attaching and Removing the gasket

When removing the gasket, refer to the illustration.

When attaching the gasket, make sure to fit the groove in the gasket completely on to the protrusion on the cap.



## Specifications

### Materials

Inner flask	Stainless steel
Outer container	Stainless steel (with acrylic coating)
Mouth (opening)	Stainless steel
Cap	Polypropylene
Gasket	Silicon

### Temperature retention

MMP-A020	Greater than 83°C / 181°F (1hour)
	Greater than 60°C / 140°F (6hour)
MMP-A030	Greater than 85°C / 185°F (1hour)
	Greater than 68°C / 154°F (6hour)

\* For the purpose of performance improvement, designs, specifications and parts shown in this publication are subject to change without notice.

2